

3. Deterioration measurement of engine oil



By installing a film sensor in an engine oil tank, the deterioration and the remaining amount of engine oil can be monitored with a deterioration meter located in a car interior.

